

# ZLAN5143K

## Rail type/desktop type

## Serial port server /Modbus gateway

RS485 TO TCP MQTT JSON ModbusTCP

Copyright ©2008 Shanghai Zlan Information Technology Co., LTD. All rights reserved

ZL DUI 20231123.1.0

The following modifications have been made to the document:



**Change log**

---

Date	Version number	Document number	Modify content.
2023-11-23	Rev.1	ZLDUI 20231123.1.0	Release version

---

### **Ownership Information**

Without the consent of the copyright owner, no part of this document may be reproduced in paper or electronic form.

This document is intended solely for assisting readers in using the product, and Shanghai ZLan Company shall not be liable for any loss or error arising from the use of the information contained herein. The products and texts described in this document are under continuous development and improvement. Shanghai ZLan Information Technology Co., Ltd. reserves the right to modify this document without prior notice to users.

# CATALOGUE

1. OVERVIEW	5
2. FUNCTIONAL FEATURES	8
2.1 Hardware Characteristics	8
2.2 Software Functions	9
2.3 Advanced Software Functions	9
3. TECHNICAL PARAMETERS	11
4. INSTRUCTIONS FOR USE	12
4.1 Hardware description	12
4.2 Hardware Connection	14
4.3 Software Installation	14
4.4 Parameter Configuration	15
4.5 TCP Communication Test	22
4.6 Virtual Serial Port Testing	25
4.7 Modbus TCP TEST	28
4.8 Web mode configuration	29
5. WORKING MODE AND CONVERSION AGREEMENT	31
5.1. Virtual Serial Port Mode	33
5.2. Direct TCP/IP communication mode	33
5.3. Equipment coupling method	39
6. EQUIPMENT COMMISSIONING	40
6.1. Network physical connection	40
6.2. Network TCP connection	40
6.3. Data Sending and Receiving	41
6.4. ZLVircom Remote monitoring data	42
7. ADVANCED FUNCTIONS OF MODBUS	44
7.1. Enable the Modbus gateway	44
7.2. Storage-type Modbus gateway	44
7.3. Disable storage-type functions	47
7.4. Multi-host function	47
7.5. Multi-host parameters	49

7.6. Modbus under Multi-destination IP	50
7.7. Configurable Modbus gateway	50
8. REGISTRATION PACKAGE AND HEARTBEAT PACKAGE	51
8.1. Registration Package	51
8.2. Heartbeat Packet	54
9. HTTPD CLIENT COMMUNICATION FUNCTION	56
10. MQTT GATEWAY	56
11. JSON TO MODBUS RTU	57
12. NTP TIME FUNCTION	57
13. MODIFY THE PARAMETERS OF THE NETWORK PORT	57
14. DEVICE MANAGEMENT FUNCTION LIBRARY	58
15. SERIAL PORT MODIFICATION PARAMETERS	58
16. REMOTE DEVICE MANAGEMENT	59
17. FIRMWARE UPGRADE METHOD	61
18. ORDERING INFORMATION	64
19. AFTER-SALES SERVICE AND TECHNICAL SUPPORT	64

---

## 1. Overview

The ZLAN5143K is an RS485 device data collector/iot gateway specifically designed for industrial environments, integrating multiple functions such as a serial server, Modbus gateway, MQTT gateway, and RS485 to JSON conversion. It has one RS485 interface and one Ethernet interface. It supports rail-mounted installation or desktop screw-hole installation (with optional rail-mounted accessories), is compact in size and easy to install. It adopts a power supply connection with terminal blocks and a wide voltage input range of 9 to 24V. It saves costs and volume and has a higher cost performance compared with ordinary products.



Figure 1 ZLAN5143K

When used as a common serial port server, the network port of 5143K is connected to the Ethernet. The upper computer software can send data to the RS485

---

interface of 5143K by TCP/UDP transparent transmission mode or virtual serial port mode. The data received on the RS485 interface will also be transmitted to the software at the TCP end or the virtual serial port. Under the virtual serial port mode, the serial port software connected to the virtual serial port can be used without the need.

When used as a Modbus gateway, the 5143K supports Modbus TCP to Modbus RTU, thereby enabling the upper computer to use the Modbus TCP protocol to collect data from the Modbus RTU devices of RS485. On the contrary, the RS485 terminal can also be used as the master station. The 5143K supports relatively advanced Modbus gateway functions, including configurable Modbus gateway ZLMB, storage-type Modbus gateway, etc., fully meeting all kinds of configurations and usages of Modbus gateways. Its supported multi-host function enables multiple computer master stations to access one RS485 slave device simultaneously.

When used as an MQTT gateway, the device can upload serial port data to the MQTT server in a transparent transmission mode using the MQTT protocol. Supported servers include Baidu Cloud MQTT, Alibaba Cloud MQTT, China Mobile OneNet platform, etc. Support parsing the collected Modbus RTU or non-standard serial port data into JSON format and encapsulating it in MQTT data packets for upload.

Support the upload of collected data in JSON format. The data is automatically collected. The collected data supports Modbus RTU, 645 instrument version 97, 645 instrument version 07, and various non-standard RS485 protocols. Users can independently configure the uploaded data format and JSON keywords using ZLVircom. When uploading, it can support MQTT protocol, HTTP POST protocol, HTTP GET protocol, transparent transport protocol, and various non-standard network protocols.

Among them, the ZLAN5143KN model supports P2P network connection, without the need for server relay, and connects to the device through ID.

The ZLAN5143K is equipped with a variety of powerful functions of an IoT gateway, making it highly suitable for the industrial field to collect data from various RS485 instruments and sensors, including local network collection or independent

---

collection and upload to cloud servers.

ZLAN5143K can be applied to:

- As an iot gateway, it serves as a communication bridge between devices and the cloud.
- Electricity, intelligent meters and energy consumption monitoring;
- Remote monitoring and program download of various RS485 interface automated PLCs;
- RS485 interfaces for communication between various configuration software and devices;
- Equipment networking in the field of access control and security;

The typical application connection is shown in Figure 2. The original serial port device RS485 is connected to the RS485 port of ZLAN5143K, and the 5143K is connected to the computer via a network cable. The software on the computer establishes a connection with 5143K via TCP/IP or virtual serial port. After that, any data sent by the serial port device will be transparently transmitted to the software of the computer, and the data sent by the software to the ZLAN5143K through the network will also be transparently transmitted to the serial port device.



Figure 2 Connection schematic diagram

## 2. Functional features

### 2.1 Hardware Characteristics

The ZLAN5143K has the following features:

1. Multi-installation method design: Supports panel installation/rail installation.
2. Compact size: Compared with ordinary serial port servers, it has a smaller width and does not take up much space.
3. Terminal power supply, wide voltage input of 9 to 24V, with reverse power protection.
4. Terminal RS485 interface, with baud rate support ranging from 300 to 921600bps.



- 
5. It is equipped with RS485 hardware interface protection.
  6. Rich panel indicator lights facilitate debugging: In terms of connection, there is not only a LINK light indicating whether the network cable is properly connected, but also a LINK light indicating the establishment of a TCP connection. For the data indicator lights, there are independent indicator lights for "serial port to network port" and "network port to serial port".

## 2.2 Software Functions

- 1 Supports TCP server, TCP client, UDP mode and UDP multicast. When acting as a TCP client, it also supports the functions of the TCP server side. As a TCP server, it supports 30 TCP connections; as a TCP client, it supports 7 destination ips.
- 2 The baud rate supports 300 to 921600bps, the data bit supports 7 to 8 bits, and the check bit can be in five ways: no check, odd check, even check, marked, and space.
- 3 Support the function of sending MAC addresses when devices are connected, facilitating cloud management of devices.
- 4 Provide a secondary development package DLL development library for searching and configuring devices on the computer end.
- 5 Support Web browser configuration, support DHCP dynamic acquisition of IP, and DNS protocol connection to domain name server addresses.
- 6 Support remote cloud search for devices, configuration of device parameters, and device program upgrades.
- 7 Support remote viewing of the TCP connection status, serial port data transmission and reception status of the device through software. The virtual serial port supports the data monitoring function.

## 2.3 Advanced Software Functions

The 5143K supports advanced software features, including:

- 1 Support Modbus gateway function and support Modbus RTU to Modbus TCP conversion. It can support storage-type Modbus, automatically collect device data and store it. It also supports Modbus gateways in non-storage mode; Support

---

the ZLMB configurable table Modbus gateway function.

- 2 Support for multi-host function: Under the question-and-answer query mode, it supports the network port end to allow multiple computers to access the same serial port device simultaneously.
- 3 Support MQTT gateway function.
- 4 Supports JSON to Modbus RTU and 645 instrument protocol, and supports data upload in HTTP POST and HTTP GET formats.
- 5 Support the NTP protocol to obtain network time, which is used for serial port output and the latter for uploading protocol content.
- 6 Supports custom heartbeat packet and registration packet functions: Facilitates communication with the cloud and device identification.
- 7 Support the function of password verification required for TCP connection establishment to ensure connection security.
- 8 It supports data submission and distribution functions via http. The cloud can directly interact with the serial port data of the device using the http GET command.

---

### 3. Technical parameters

Table 1 Technical Parameters

Outline			
Interface:	RS485		
Power supply:	Terminal mode		
Size:	L x W x H =4.8cm×2.5cm×6.1cm （±1mm）		
Communication			
Ethernet:	RJ45		
Serial port:	RS485×1:		
Serial port parameter			
Baud rate:	300~921600bps	Check bit:	None, Odd , even Mark, Space
Digit bits:	7~8bits	Flow control:	RTS/CTS, DTR/DCR, NONE
Software			
Protocol:	ETHERNET、IP、TCP、UDP、HTTP、ARP、ICMP、DHCP、DNS		
Configuration:	ZLVirCOM tool, WEB browser (can customize the web page), device management function library, serial port AT command configuration, device cloud management (ZLan server)		
communication method:	Socket、virtual serial port、Device management library		
Working mode			
TCP server, TCP client, UDP, Real Com Driver, Modbus TCP, Telnet			
Power supply:			
Power:	9~24V DC;30mA@12V DC		
Environment requests			
Operation temperature:	-40~85℃		
Storage temperature:	-45~120℃		
Humidity range:	5~95% humidity accordingly		

## 4. Instructions for Use

### 4.1 Hardware description

The front view of the ZLAN5143K serial port server is shown in the above picture. The optional rail clamps support 35mm standard rail installation.

Figure 3 Frontal view

- 1 Power input: Terminal block, supporting input voltage of 9




Figure 4 Power supply and network port

- 2 RS485: Use the RS485 terminal interface.

- 3 Network port: Connect the network cable and support automatic cross-connection.
- 4 Indicator lights: They are divided into Power (PWR), Link(LNK), and Active(ACT) lights, which respectively indicate power, connection, and data.
- 5 Reset: Hold down the reset button shown in the above picture for more than 5 seconds. The module will reset to the IP address of 192.168.1.254, and all downloaded configuration files will not be loaded.

Table 2 Meanings of Indicator Lights

Power	Power indicator light
Link	<p>(1) Link is green when the network cable is properly connected.</p> <p>(2) When a TCP connection is established (or in UDP mode), the Link is blue (actually with a faint green light). It can be used to determine whether the serial port server establishes a communication link with the host software.</p>
Active	<p>(1) (1) When the network port sends data to the serial port, the indicator is green. The flashing time is one second longer than the actual communication time, making it easier to detect short data communications.</p> <p>(2) When the serial port is sending data to the network port, the indicators are on both blue and green. If the blue color is displayed, the serial port returns data to the network port. This can determine whether the device has a response to the command of the upper computer, if there is no corresponding indicates that the serial port baud rate is not correct or the serial port is not connected.</p>

Debugging communication method using indicator lights:

- 1) If the Link light is not green, the network cable is not properly connected. Please check the network cable.
- 2) If the Link light is not blue (only considering the TCP working mode), the upper computer software has not established a connection with the serial server. Please consider whether the IP addresses are configured in the same network segment.
- 3) If the Active light is green, it indicates that data is sent from the network port but

---

no serial port device is returning data. Please check whether the baud rate is properly configured and whether the RS485 has poor contact.

- 6 **Installation method:** If the equipment is equipped with 35mm standard guide rail clips, and there are guide rails, the equipment can be directly installed into the guide rails. Or it can be installed with desktop screws.



Figure 5 The back of the equipment

Figure 5 contains the guide rail clips selected by the customer. Please inform us in advance of the price change when placing an order.

#### 4.2 Hardware Connection

Generally speaking, a serial server only needs to be connected to the power supply, RS485 serial port and network cable.

Among them, the power supply can adopt the 2-wire 9-24V DC power supply on site. It can be directly connected to the positive and negative terminals of the power supply, or the power adapter we provide can be used to power the equipment.

Among them, the RS485 serial port needs to be connected according to the user's serial port RS485 device.

The network port can be connected to a regular network cable. It can be directly connected to a computer or connected to the network through a switch.

#### 4.3 Software Installation

ZLVircom can be used to configure parameters such as device IP and create

virtual serial ports. If the virtual serial port function is not required, the installation-free version can be downloaded. Download link:<http://www.zlmcu.com/download.htm>

Table 3 Versions of ZLVircom

Software name	Specifications
ZLVircom Device Management Tool (non-installed version)	The non-installed version does not include the virtual serial port function.
ZLVircom-Device Management Tool (Installation version)	The installed version contains ZLVircom_x64.msi and ZLVircom_x86.msi. 64-bit operating systems install x64, 16-bit operating systems install x86 versions.

Just follow the default prompts when installing. After the installation is completed, zlvircom will be launched each time the computer starts up, which is used to create a virtual serial port at startup.

#### 4.4 Parameter Configuration

After ZLVircom is installed and equipment hardware connection is completed, ZLVircom software is run as shown in the figure, and then click "Equipment management" as shown in the figure. ZLVircom can be used to search and configure equipment parameters in different network segments, which is very convenient, as long as the equipment and the computer running ZLVircom are in the same switch.




Figure 6 Main Interface of ZLVircom




Figure 7 List of devices

See all the currently online devices from the device list. Click "Edit Device" to configure the parameters.



The screenshot shows a 'Device Settings' window with the following sections:

- Device Info:** Virtual Serial (Not Use), Dev Type, Dev Name (000000001), Dev ID (28785B60319E), MAC Addr (28785B60319E), Firmware Ver (V1.614).
- Function of the device:** Web Download, DNS System, REAL\_COM Protocol, Modbus TCP To RTU, Serial Commnad, DHCP Support, Storage Extend, Multi-TCP Connection.
- Network:** IP Mode (Static), IP Address (192.168.1.200), Port (4196), Work Mode (TCP Server), Net Mask (255.255.255.0), Gateway (192.168.1.1), Dest. IP/Domain (192.168.1.3), Dest. Port (4196), UDP Dynamic.
- Serial:** Baud Rate (115200), Data Bits (8), Parity (None), Stop Bits (1), Flow Control (None).
- Advanced Settings:** DNS Server IP (8.8.4.4), Dest. Mode (Dynamic), Transfer Protocol (None), Keep Alive Time (60s), Reconnet Time (12s), Http Port (80), UDP Group IP (230.90.76.1), Register Pkt, Restart If No Data (every 300 Sec), Enable Parameter Send (every 5 Min), Framing Rule (Max Frame Length 1300 Byte, Max Interval 3 Ms).

Buttons at the bottom: Get Default, Save As Default, Load Default, Modify Key, Firmware/Config, Restart Dev, Modify Setting, Cancel.

Figure 8 Equipment parameters

In this interface, users can set the parameters of the device and then click "Modify Settings". The parameters will be set to the device's flash and will not be lost in case of power failure. Meanwhile, the device will restart automatically.

The main parameters configured here are: baud rate, data bit, and parity bit in the serial port Settings; IP address, subnet mask and gateway in network Settings; Sometimes, based on computer software, it is also necessary to configure the working mode of the serial server.

The detailed meanings of other parameters are as follows:

Table 4 Parameter Meanings

Parameter name	value range	Contents
virtual serial port	none, created virtual serial port	You can bind the current device to an existing virtual serial port. Add a COM port in Serial Port Management on the home screen.
Device model		Only the model of the core module is displayed
Device name	random	You can give the device an easy-to-read name, up

		to 9 bytes, support Chinese names.
Device ID		factory unique ID, cannot be modified.
Firmware version		Firmware version of the core module
Functions supported by the device		See Table 3 for features supported by the device
IP mode	static、DHCP	Users can choose between static or DHCP (dynamic IP acquisition)
IP address		IP address of the serial port server
Interface	0~65535	<p>Listening port of the serial port Server in TCP Server or UDP mode. If you use port 0 as the client, you are advised to set port 0 to improve the connection speed. If port 0 is used, the system randomly assigns a local port. The difference between this and non-zero port is: (1) When the local port is 0, a new TCP connection is established with the PC when the module restarts, and the old TCP connection may not be closed, and the device may have multiple fake connections. Generally, the host computer wants to close the old connection when the module restarts; Specifying a non-zero port closes the old connection. (2) If the local port is 0, the TCP connection takes a shorter time to re-establish.</p> <p>When the serial port server is in TCP client mode, it also acts as the TCP server to listen for incoming connections on the port. In this case, the local port number used by the TCP client to connect to the server is Port +1000.</p>
Working mode	TCP server mode, TCP	When set to TCP server, the serial server waits for

	client mode, UDP mode, UDP multicast mode	the computer to connect. If TCP client is configured, the serial port server initiates a connection to the network server specified by the destination IP address.
Subnet mask	For eg.: 255.255.255.0	The subnet mask must be the same as that of the local LAN.
Gateway	For eg.: 192.168.1.1	It must be the same as the local LAN gateway
Destination IP address or domain name		In TCP client or UDP mode, data is sent to the computer indicated by the destination IP or domain name.
Destination port		In TCP client or UDP mode, data is sent to the destination port of the destination IP address.
Baud rate	300、600、1200、2400、4800 、 7200 、 9600 、 14400、19200、28800、38400、57600、76800、115200 、 230400 、 460800、921.6K	Serial port baud rate
Digit bits	5、6、7、8、9	
Check bits	None, Even, Odd, tag, space	
Stop bits	1、2	
Flow control	No flow control, hard flow control CTS/RTS, hard flow control DTR/DCR, soft flow control XON/XOFF	Only available for RS232 serial port
DNS server		If the destination IP address is described by a domain name, enter the IP address of the DNS server. If the IP address mode is DHCP, you do not

		need to specify the DNS server. The DNS server automatically obtains the IP address from the DHCP server.
Destination mode	Static , dynamic	TCP client mode: In static destination mode, the device automatically restarts after five consecutive failed attempts to connect to the server.
Transfer protocol	NONE 、 Modbus TCP<->RTU 、 Real_COM、 TELNET	NONE indicates that data is transmitted transparently from the serial port to the network. Modbus TCP<->RTU will convert Modbus TCP protocol directly into RTU protocol, which is convenient to cooperate with Modbus TCP protocol; RealCOM is designed to be compatible with the older version of the REAL_COM protocol. It is a virtual serial port protocol. However, it is not necessary to select the RealCom protocol when using the virtual serial port. The TELNET protocol allows the network to log in to our device through TELNET to communicate with the serial port
Keepalive timing time	0~255	Heartbeat interval. (1) If the value ranges from 1 to 255 and the device is in TCP client working mode, the device automatically sends TCP heartbeat packets at Keepalive intervals. This ensures the TCP validity of the link. If the value is set to 0, there is no TCP heartbeat. (2) If the value is set to 0 to 254, and the conversion protocol is REAL_COM, the device will send data with length 1 and content 0 at keepalive intervals to implement the heartbeat mechanism in the Realcom protocol. If the value is set to 255, there is no realcom heartbeat. (3) When the value is set to 0 to 254, if

		the device works on the TCP client, the device will send device parameters to the destination computer at keepalive intervals. If the value is set to 255, no parameter is sent, enabling remote device management.
Disconnected reconnection time	0~255	In TCP client mode, when the connection fails, the TCP connection is re-initiated to the computer at disconnection Reconnection time intervals. The value ranges from 0 to 254 seconds. If the value is set to 255, the reconnection is never performed. Note that the first TCP connection (such as hardware power-on, device restart through zlvircom software, and no data light) is generally carried out immediately, and only after the first connection fails will it wait for the "disconnection reconnection time" to try again, so the "disconnection reconnection time" will not affect the normal connection establishment time between the network and the server.
Web access port	1~65535	Default is 80
Multicast address		Under UDP multicast
Enable registration package		When a TCP connection is established, the registration packet is sent to the computer. The realcom protocol must be selected after the registration package is enabled. TCP server and TCP client modes are supported.
Digit packet length	1~1400	One of the serial port framing rules. Serial port server After receiving data of this length, the serial port sends the received data to the network as one

		frame.
Packet interval	0~255	Serial frame rule 2. When the data received by the serial port server stops for a period longer than the specified period, the received data is sent to the network as a frame.

The functions supported by the device are described as followings:

Figure 5 Device supported functions

Name	Specifications
Domain name system	The destination IP address can be a domain name (such as the first www server address).
REAL_COM protocol	A non-transparent serial port server protocol, suitable for multiple serial port servers to bind virtual serial ports over the Internet. Because the protocol contains the MAC address of the device, it helps the host computer to identify the device. Generally, it can not be used.
Modbus TCP to RTU	Can realize Modbus TCP to RTU. It also supports the multi-host function.
Serial port modification parameter	Support serial port class AT instruction to configure and read device parameters.
Automatic acquisition IP	Support DHCP client terminal protocol
Multi TCP connection	The TCP server supports more than one TCP connection.
UDP broadcast	UDP broadcast
Multi purpose IP	As a TCP client, seven destination IP addresses can be connected at the same time.
P2P function	Supports the function of accessing devices in any network through P2P traversing technology. Models ending in N support this function.

#### 4.5 TCP Communication Test

After device parameters are configured, you can use the serial port tool or TCP debugging tool to test the TCP connection.




Figure 9 Schematic Diagram of TCP communication

Assuming the PC COM port (USB turn RS485 lines) and serial port serial port server connection, then open the ZLComDebug (<http://www.zlmcu.com/download/Comdebug.rar>) serial debugging assistant, and open the corresponding COM figure 10; Open TCP&UDP debugging assistant SocketTest (<http://www.zlmcu.com/download/SocketTest.rar>), and as a way of TCP client, fill in the destination IP for a serial port server IP (currently 192.168.1.200), The destination port is 4196, and then click the "Open" button. In SocketTest, enter "socket send" and click Send. Then the data will be transferred to the RS485 interface through the network port of the serial server, and then sent to ZLComDebug, and then displayed in ZLComDebug. Conversely, in ZLComDebug, enter "Comdebug send", click send, and it can also be sent to socket test and displayed.

The transparent data forwarding function of serial port to network port and network port to serial port of the serial port server.




Figure 10 comdebug transceiver Interface






Figure 11 sockettest transceiver interface

#### 4.6 Virtual Serial Port Testing

The SocketTest in the figure communicates directly with the serial server via TCP. To enable the user's already developed serial software to communicate with the serial server, a virtual serial port needs to be added between the user program and the serial server. As shown in Figure 12, ZLVircom and the user program run on one computer. ZLVircom virtualizes a COM port and makes this COM port correspond to this serial server. When the user program opens COM communication, it can be sent to the user's serial port device through the ZLVircom serial port server. The following demonstrates this operation step:



Figure 12 Functions of the virtual serial port

Click "Serial port management" in the main interface of ZLVircom, then click "Add", select to add COM5, where COM5 is the COM port that does not exist in the computer.

Figure 13 Add virtual serial port

Then go to Device Management and double-click the device that you want to bind to COM5. Select COM5 from the Virtual Serial Port list in the upper left corner. Then click "Modify Settings". And return to ZLVircom's main interface. You can see that COM5 has connected to the device whose IP address is 192.168.1.200. COM5 can be used instead of SocketTest to communicate at this time.




Figure 14 virtual serial port is connected

Open ZLComdebug to simulate the user's serial port program, open COM5(the above virtual serial port), and open a ZLComdebug to simulate a serial device, open COM4(hardware serial port). The data link sent by COM5 is as follows: COM5ZLVircom serial port Server network port Serial port Server serial port COM4. Conversely, COM4 to COM5 can also transmit data: COM4 serial port server serial port Serial port server network port ZLVircomCOM5. Figure 22 shows the two parties sending and receiving data.

If the COM4 is replaced by the user serial port device, the COM5 can realize the communication with the user device.




Figure 15 Communication through the virtual serial port

#### 4.7 Modbus TCP TEST

By default, serial port and network port data are transmitted transparently. If you need to convert Modbus TCP to RTU, you need to select "Modbus TCPRTU" as the conversion protocol in the device setup dialog box, as shown in Figure 23. In this case, the device port automatically changes to 502, and the Modbus TCP tool connects to port 502 of the serial port server IP address. The Modbus TCP command is converted to RTU command and output from the serial port. For example, if the port of the serial port server receives the Modbus TCP command 00 00 00 00 00 06 01 03 00 00 00 00 0a, the serial port outputs the command 01 03 00 00 00 00 0a c5 cd. Note: The serial port may send more than one 01 03 00 00 00 00 0a c5 cd

command, this is because the default Modbus is stored mode, will automatically rotate the query command. I'll explain how to switch to non-storage mode later.




Figure 16 Enable Modbus TCP function

If the Modbus TCP software of the user is used as the Slave station, it is necessary to change the working mode to the client on the basis of selecting the conversion protocol, change the destination IP address to the IP address of the computer where the Modbus TCP software is located, and the destination port is 502, as shown in Figure 17.




Figure 17 Modbus TCP as client side

#### 4.8 Web mode configuration

ZLVircom can search and configure device parameters in different network

---

segments. Web configuration requires first to ensure that the computer and the serial server are in the same IP segment, and the IP address of the serial server needs to be known in advance. But Web configuration can be done on any computer without ZLVircom.

1. In the address box of your browser, enter the IP address of PORT1 of the serial port server, for example, <http://192.168.1.200>.




Figure 18 Login interface

2. Enter a Password in Password: there is no password by default. Click the login button to sign in.

The image shows the ZLAN web configuration interface. At the top is a blue header with the 'ZLAN' logo on the left, 'Chinese' language selection, and a 'Logout' button on the right. Below the header is a sidebar on the left with 'Device Configuration' (highlighted), 'Windows Tool', and 'Service Center'. The main content area contains several configuration panels:

- Device Information:** Fields for Device Name (<DVN>), Device ID, and Firmware Version (V1).
- Serial Settings:** Fields for Baudrate (>1200), Data Bits (>8), Parity (>None), Stop Bits (>1), and Flow Control (>None).
- Network Settings:** Fields for IP Addressing (>Static), IP Address (<LCA>), Local Port (<LCP>), Mode (>TCP Server), Subnet Mask (<LCM>), Gateway (<LCG>), Destination IP/DNS (<DSA>), Destination Port (<DSP>), and Web Port (<WBP>).
- Multi-Master Settings:** Fields for Protocol (>None), Response Timeout (<RTO> with a range of 32~8000ms), Multi-Master (>Disable), and Transmit Delay (<RCG> with a range of 5~255ms). A note states: 'NOTE: When the multi master is disabled, the response timeout will always be 0. The timeout must be a multiple of 32'.
- Advanced Settings:** Fields for Watchdog Reset (>Disable), Watchdog Reset Time (<NRT> with a range of 5~1270 s), and Re-connect Time (<RCT> with a range of 1~255 s).
- Modify Web Password:** Fields for New Password (masked with dots) and Confirm Password (masked with dots).

Figure 19 Web Configuration Interface

3. You can modify serial port server parameters in the displayed web page. For details about related parameters, see Table 4.
4. Click the "Submit Modification" button after modifying the parameters.

## 5. Working mode and conversion agreement

In different applications can choose different serial server working mode, conversion protocol, so as to be more stable and reliable use, the following details.

The use of serial port server is basically divided into two types: with virtual serial port and non-virtual serial port, as shown in Figure 9 TCP communication diagram and Figure 12 function of virtual serial port respectively. The user software that needs to be connected with the virtual serial port is a serial port (COM port), that is, the user software and the user device are serial ports. Non-virtual serial port mode The user software is directly TCP/IP communication but the user device is still serial port.

In the non-virtual serial port mode, the "conversion protocol part" is divided into transparent transmission, Modbus TCP to RTU and Realcom protocol three modes. If the user software uses the Modbus TCP protocol and the lower computer uses

Modbus RTU, select Modbus TCP to RTU. The Realcom protocol is used only when the multi-serial server serves as the TCP client to connect to a server and the virtual serial port is used on the server.

Usage is summarized as follows:

Table 6 Network configuration modes

No.	Virtual serial port usage	device working mode	Transfer protocol	Specifications
1	Use	TCP server	none	It is suitable for the occasion when the user software opens COM port to collect data actively.
2	Use	TCP client	none	If the TCP server is selected, the device may fail to reconnect after disconnection.
3	None	TCP server	Modbus TCP to RTU	The user software is Modbus TCP and the user device is Modbus RTU. And the Modbus TCP master station.
4	None	TCP client side	Modbus TCP to RTU	The user software is Modbus TCP and the user device is Modbus RTU. And Modbus RTU is the master station.
5	Use	TCP client side	Realcom protocol	When the multi-serial port server serves as the TCP client and the virtual serial port is used, the Realcom protocol is recommended.
6	None	TCP server	Telnet protocol	This mode applies to monitoring device serial ports when connecting to



				the Zlan serial port server over Telnet.
7	None	TCP client side	None	It is suitable for connecting a cloud with a large number of devices. In general, the cloud is a server with a public IP address on the Internet.

### 5.1. Virtual Serial Port Mode

If the user software uses the COM port to communicate, it must use the virtual serial port mode. Including some PLC software, configuration software, instrument software and so on.

Then see if the monitoring computers and devices are on the local network:

a) If the computer is a server with a public IP address leased on the Internet, the device must use TCP client mode to connect the device to the server. In this case, you can select 2 and 5 in Table 6. If multiple serial servers are used, you must select 5.

b) All in the local network (can ping each other), it depends on whether the host computer actively queries or the device actively sends data. If the device acts as the TCP client to send packets, mode 2 must be used. Otherwise, mode 1 can be used.

### 5.2. Direct TCP/IP communication mode

If the Modbus TCP protocol is not required and the virtual serial port is not required, the user software may directly communicate with the network port of the serial port server for TCP/IP communication, and the serial port server converts TCP/IP data to serial port data and sends it to the serial port device.

Generally, the user of this kind of usage develops the host computer network communication software by himself, which integrates the analysis of the serial communication protocol of the device. This method is more flexible and efficient than

---

virtual serial port. Correspond to ⑥ and ⑦ in Table 6.

The section "4.6TCP Communication Tests" mainly describes how to communicate when the serial server acts as a TCP server. Here we will talk about how TCP clients, UDP mode, and multi-TCP connections communicate with computer software. The Ttest computer software is based on SocketTest (software that mimics user TCP/IP communication) as an example.

ZLAN serial server complies with the standard TCP/IP protocol, so any network terminal that complies with the protocol can communicate with the serial server, ZLAN technology provides a network debugging tool (SocketDlgTest program) to simulate the network terminal to communicate with the serial server.

For two network terminals (in this case, the network debugging tool and the serial server) to communicate, their parameter configurations must be paired.

#### 5.2.1. TCP Client Mode

There are two working modes in TCP mode: TCP server and TCP client. No matter which mode is used, one side must be the server and the other side is the client, and then the client can access the server.

When the serial server is the client, there must be three relationships, as shown in Figure 20. (1) Working mode: The working mode of the serial port server is the server mode of the network tool corresponding to the client. (2)IP address: The destination IP address of the serial port server must be the IP address of the computer where the network tool is located. (3) Port: The destination port of the serial port server must be the local port of the network tool. After this setting, the serial port server can automatically connect to the network tool and send and receive data after the connection is established.




Figure 20 Serial server as client

### 5.2.2. The client connects to multiple servers

When the ZLAN serial port server serves as the TCP client, seven destination IP addresses can be connected at the same time. Data sent from the serial port is sent to all seven destination IP addresses at the same time. If there are not that many servers, the rest of the destination IP is vacant. Its use is as follows:




Figure 21 First destination IP address and port number

---

Multi Dest-IP And Port		
IP Address or DNS name	Port	Type
192.168.1.100	1024	Client Dest. ▼
192.168.1.101	1025	Client Dest. ▼
192.168.1.102	1026	
192.168.1.103	1027	
192.168.1.104	1028	
192.168.1.105	1029	

Figure 22 left 2~7 IP and terminals

The first IP address is set in the device setup screen shown in Figure 21, where the first IP address can be a domain name. Remaining 2 to 7 destination IP addresses On the device Settings screen, click More Advanced Options to open more advanced options.

All seven destination IP addresses can be automatically connected after being set. If the destination IP addresses fail to be connected, they are reconnected repeatedly after the Disconnection time.

### 5.2.3. TCP Server Mode

When the serial server acts as the server, there are also three mappings, as shown in Figure 23, which are not explained here. After this setting, click the open button of the network tool to establish a TCP connection with the serial port server. After the connection is established, you can send and receive data.




Figure 23 Serial server as server

When the serial port server serves as the server, it can accept 30 TCP connections at the same time. The data received by the serial port is forwarded to all established TCP connections. If you want to send data only to the TCP that recently received network packets, you need to enable the multi-host function. For details, see 7.4 Multi-Host Function.

#### 5.2.4. Act as both the client and the server

Zlan serial port server supports the device in the TCP client mode can also accept TCP connections, that is, also has the TCP server function.




Figure 24 is both a client and a server

By default, when ZLVircom is configured, if the working mode is changed to

"TCP client" mode, the port (that is, the local port) will automatically become 0 (0 means that an idle port is randomly selected). In order to support the TCP server mode, the computer software must know the local port of the device, so a value needs to be specified here. As shown in Figure 24, the computer software can now connect to port 5001 of 192.168.1.200 for communication. In addition, the device acts as a client and connects to port 1024 of 192.168.1.189. Note that because the local port 1024 is occupied by the server, the local port used by the client is "port +1", that is, the software on 192.168.1.189 sees that the incoming port of the device is 1024+1=1025.

#### 5.2.5. UDP Mode

In UDP mode, parameter configuration is shown in Figure 25. The left side is the configuration of serial server in ZLVircom, and the right side is the setting of network debugging tool SocketDlgTest. First, both must be in UDP working mode. In addition, the destination IP address and port of the network tool must point to the local IP address and port of the serial port server. The blue arrow indicates that the destination IP address of the serial port server must be the IP address of the computer where the network tool is installed, and the destination port of the serial port server must be the local port of the network debugging tool. These network parameters must be configured to ensure two-way UDP data communication.




Figure 25 UDP mode parameter configuration

5.3. Equipment coupling method

If the host computer is not a Socket program (SocketDlgTest) or a virtual serial port, but two devices are connected through network ports, the configuration method is similar. First, the user needs to connect two devices and computers to the same LAN. ZLVircom runs on this computer, the purpose of connecting the computer is only for configuration, and the computer does not need to be connected after configuration.

Click on ZLVircom's device management to find these two devices, as shown in Figure 26. Then click "Device Edit" to configure the device. Device pairs can be classified into TCP pairs and UDP pairs. In TCP interconnection mode, the parameters of the two devices are shown in Figure 20. The parameters shown by the arrows must correspond to each other, just as they correspond to the PC connection. After the TCP connection is successful, you can return to the Device Management dialog box to check the connection status, as shown in Figure 26. If the status of both devices is Connected, the TCP link between the two devices has been established.




Figure 26 Configuration of TCP device pairing parameters

Device Management														✕	
I...	T...	Name	ty...	f	Dev IP	Loc...	Dest IP	Work M...	TCP Con...	Virtual...	Vircom ...	Dev ID	T...	Auto Search	
1	S...	DEV0001			192.168.1.2...	41...	192.168.1.3	TCP Client	Establish...	Haven'...	Not Link...	5B603199	0		
2	S...	DEV0001			192.168.1.2...	41...	192.168.1.3	TCP Serv...	Establish...	Haven'...	Not Link...	5B60319E	0		

Figure 27 Successful connection check of TCP devices

For UDP couplings, the configuration parameters are shown in Figure 28. The parameters corresponding to the arrows must be one-to-one. UDP pair connection



Data is automatically sent to the specified device if the parameters are correctly configured without checking the connection status.

The image shows two identical network configuration windows side-by-side. Each window has a 'Network' section with the following fields: IP Mode (Static), IP Address, Port, Work Mode (UDP), Net Mask (255.255.255.0), Gateway (192.168.1.1), Dest. IP/Domain, and Dest. Port. In the left window, a yellow box highlights the IP Address (192.168.1.200), Port (1024), and Work Mode (UDP). In the right window, a red box highlights the IP Address (192.168.1.201), Port (1025), and Dest. IP/Domain (192.168.1.200). Both windows have a green box around the Work Mode (UDP) dropdown.

Figure 28 Configuration of UDP device pairing parameters

Finally, you need to remind that if the device is in pair, in addition to the network port parameters according to the above Settings, you must also set the correct serial port parameters. The baud rate of the serial port server must be consistent with that of the user's device. After this configuration, user devices can send data to each other through the serial ports of the two serial servers.

## 6. Equipment commissioning

### 6.1. Network physical connection

The serial port server can be connected to the switch or the computer network port using a crossover cable or a direct network cable.

After the connection is established, check whether the Link indicator is green. Otherwise, check whether the network cable is properly connected.

### 6.2. Network TCP connection

When the device is used as a dynamic way to obtain IP, it cannot be directly connected to the computer network port. Because there is no DHCP server available (generally, a DHCP server is a router in a local area network). So when connecting directly, please specify the IP address. Meanwhile, the computer also needs to specify



a fixed IP.

Network

IP Mode: Static

IP Address: 192 . 168 . 1 . 201

Port: 1025

Work Mode: TCP Server

Net Mask: 255 . 255 . 255 . 0

Gateway: 192 . 168 . 1 . 1

Figure 29 configure into the same network segment

Whether connected directly or through a switch, when configured with static IP, the device and the computer need to be on the same network segment (unless communicating across gateways), as shown in Figure 29.

Since ZLVircom supports cross-network segment search and configuration, the IP addresses that can be searched but cannot be communicated are generally not well configured. In this case, ZLVircom can be used to configure devices on the same network segment.

After the configuration is complete, perform the steps in 4.6 TCP Communication Test or 4.7 Virtual Serial Port Test. You can see that the Link indicator turns blue when a TCP connection is established. The blue Link light can also be seen through ZLVircom. For example, in the device management list, if the TCP connection is listed as "established", the Link light is blue, as shown in Figure 30, which can facilitate remote diagnosis.

Device Management														✕	
I...	T...	Name	ty...	f	Dev IP	Loc...	Dest IP	Work M...	TCP...	Virtual...	Vircom ...	Dev ID	T...	R...	
1	S...	DEV0001			192.168.1.2...	41...	192.168.1.3	TCP Serv...	Estab...	Haven'...	Not Link...	5B60319E	0	0	Auto Search

Figure 30 Connection status and data sending and receiving status

### 6.3. Data Sending and Receiving

When the Link indicator turns blue, data can be sent and received between the software and the serial port server. If the software sends data, the Active light turns green for at least one second. Data is also output from the serial port of the serial port

---

server, but whether the output data is correct depends on whether the correct serial port parameters (baud rate, data bit, stop bit, check bit) are configured.

The serial port device responds to correct command delivery. Once a response is received (the serial port sends data to the network port), the Active color turns blue. Otherwise, check whether the serial port parameters or the serial cable are connected properly.

In order to facilitate remote debugging, ZLVircom also supports remote viewing of data sent and received. As shown in Figure 30, TXD is the amount of data sent by serial port server. When refreshing the device list, if the value changes, it indicates that data has been sent, and the Active light will turn green. If you see the value of RXD changing, it indicates that the serial device has returned data, and Active is blue.

#### 6.4. ZLVircom Remote monitoring data

In the case of using virtual serial port, ZLVircom supports real-time capture of data sent and received by virtual serial port. Convenient for users to debug the system, the use method is as follows:

Assume that the communication of the virtual serial port has been established according to the method of 3.4.7 Virtual Serial Port test. Now you need to monitor the data through the virtual serial port. Open ZLVircom's menu/Configuration/Software configuration/Open vircom configuration dialog box.




Figure 31 enables ZLVirocm monitoring

Check the three options of enable monitoring, hexadecimal monitoring mode, and display data sending and receiving time, as shown in Figure 31. Then click OK. Assuming that data has been sent and received before, now select a virtual serial port

that you want to monitor in the main interface, and then select Menu/View/Monitor, as shown in Figure 32.




Figure 32 Open ZLVirocm monitoring

From the open dialog box, you can see the instructions sent by the host computer and the instructions returned by the device, as shown in Figure 33. This function can facilitate the field communication debugging.




Figure 33 Monitoring and receiving data

---

## 7. Advanced Functions of Modbus

Serial port server with Modbus gateway function itself does not have station address and register, it is a communication bridge, it will generate Modbus RTU specification according to the user software to Modbus gateway in the Modbus TCP instruction, function code, register number, register number, and output from the serial port. Think of it as a protocol "translator."

### 7.1. Enable the Modbus gateway

First of all, the serial port server should support Modbus gateway, that is, the function of "Modbus TCP to RTU" in the function supported by the device in Table 3 of the device setup dialog box should be checked.

By default, the serial port server is in common transparent mode. If you want to switch to Modbus gateway mode, select Modbus TCPRTU in Conversion Protocol. The device automatically changes Port to 502 (port of the Modbus server). The Modbus gateway is enabled.

When the serial port RTU device serves as the slave station, the Modbus TCP software on the upper computer connects to port 502 of the Modbus gateway, and the Modbus gateway needs to work in TCP server mode. If serial port RTU is used as the primary station, the Modbus gateway works on the TCP client, and the destination IP address is the IP address of the computer on which the Modbus TCP software is installed. The destination port is usually 502.

### 7.2. Storage-type Modbus gateway

ZLAN5143K is a regist-saving Modbus gateway. ZLAN5143K can save the contents of read registers inside the gateway, so the Modbus TCP query speed can be greatly improved, and the performance is better when supporting multi-host access.




Figure 34 Storage Modbus gateway working mode

As shown in Figure 34, the Modbus TCP command is first converted into the corresponding command of Modbus RTU, and then the device responds to the Modbus RTU command to the Modbus gateway, and then the Modbus gateway is converted into Modbus TCP and sent to the monitoring host computer.

We know that Modbus TCP is a network communication, the transmission speed is very fast, generally within 3ms can answer, while Modbus RTU is RS485, generally only 9600bps speed, generally send and return an instruction at least 30ms. In this way, the query response time of the common non-storage Modbus gateway is relatively long. In addition, if there are a lot of upper computers to query data at the same time, then the serial port will be congested. If the network is like a highway and the serial port is like a single-log bridge, then the original way is to pass the traffic of the highway on the single-log bridge.

The register-saving Modbus gateway (ZLAN5143K) solves the above problems. It can temporarily save the register data obtained by the query in the Modbus gateway, so that when the Modbus TCP query comes, the Modbus gateway can immediately

---

return the command, and really bring the fast characteristics of Modbus TCP into play. On the other hand, ZLAN5143K can actively send instructions from the serial port to automatically update the data content of the currently saved register and save a copy of the latest register value.

In addition, ZLAN5143K is a fully automatic configuration free Modbus gateway, the user does not need to configure the required register address, function code, slave station address, etc. ZLAN5143K automatically identifies and dynamically adds these registers according to the Modbus TCP command sent by the network port.

ZLAN5143K can show good response speed when monitored by multiple computers, no matter what baud rate the serial port is, it can generally give the host response data within 3ms. And it shows a good speed of real-time update of serial data.

The register-saving Modbus gateway is the real Modbus TCP to Modbus RTU, which really plays the advantages of fast Modbus TCP and multi-host query at the same time.

Notice When the serial port server serves as the TCP client, it does not have the storage function and automatically switches to the non-storage mode.

The features of storage Modbus are listed below:

1. The first Modbus TCP query instruction is non-stored. Because you must wait for the RTU device to return the data slowly before you can return the register contents to the network port.
2. If a specific command is no longer queried by the host computer on the network within 5 seconds, the command is automatically deleted and no longer sent from the serial port to the RTU device.
3. Currently, 10K Modbus cache can be stored, and about 500 instructions can be stored at the same time for ordinary single-register queries.
4. When multiple instructions are queried at the same time, they are sent in order of priority. The first instruction is sent and the first instruction is answered 485 anti-conflict time (refer to the multi-host part) the second instruction is sent..... . Do not return to the first command until the last command has been answered.
- 5.

---

### 7.3. Disable storage-type functions

Although the memory Modbus has a fast response speed, some users do not want the RTU device to not want to receive a large number of query instructions, which affects the internal processing speed of the instrument. At this point, you can disable the storage function.

To disable the storage type, click the "More Advanced Options" button in the "Parameter Configuration" dialog box, remove one support and one enable as shown in Figure 35, and then click OK. Then go back to device Settings and click Modify Settings.

Notice When you configure the conversion protocol in Web mode, it is a non-storage Modbus gateway by default.




Figure 35 new version zlvircom setting

### 7.4. Multi-host function

The "RS458 multi-host support" and "RS485 bus collision detection function" shown in Figure 35 are the multi-host functions of Zoran. They are generally enabled and disabled simultaneously. After this function is enabled, the device whose protocol is converted to Modbus TCP has the function of a storage Modbus gateway; otherwise, it is a non-storage Modbus gateway. If the conversion protocol is none, the user-defined RS485 protocol can generally also have the function of a serial port device accessed by multiple hosts at the same time, which can not be achieved in a pure RS485 network, because multiple master stations will send conflicts on RS485 at the same time. The multi-host of ZLAN serial server can "coordinate" RS485 to

---

achieve the purpose of multi-host access.




Figure 36 Multi-host function demonstration

As shown in Figure 36, in ordinary mode, when two hosts, host A and host B, are connected to the serial port server at the same time, host A sends (1) instruction, RS485 device receives (2) instruction, RS485 device returns (3) instruction, but the serial port server sends (4) to host A and (5) to host B at the same time. Because host B did not send the query, but it also received the reply instruction (5), host B may generate a communication exception error. In multi-host mode, there will be only instructions (4) and no instructions (5), because the serial server will automatically remember the host that needs to be returned, and only the command will be returned to the most recent communication host, host A queries will only reply to A, host B queries will reply to host B.

Another effect is that in normal mode, host A and host B send data at the same time, which will produce a combination of instructions on the RS485 bus, so that it can not be recognized normally; In the multi-host mode, the serial port server can schedule the sequence of A and B in using the bus, so as to effectively solve the conflict problem of multi-machine simultaneous access.

If the conversion protocol is set to None, the multi-host function is disabled by default. To enable the multi-host function, click More Advanced Options in the device configuration dialog box and select RS485 Multi-Host Support.



---

## 7.5. Multi-host parameters

“The meanings of RS458 Multi-host support and RS485 bus conflict detection are described as follows.



Figure 37 RS485 multi-host support

The response timeout period of an RS485 command is as follows: Indicates the maximum interval between sending the command and receiving the response from the serial port on the server. The value must be greater than the actual maximum interval. Because if it is determined to be a timeout, the next instruction will be sent.




Figure 38 Free time of RS485 conflict prevention

RS485 bus collision time: indicates how many milliseconds the serial port server waits to send the second command after receiving the reply of the first command. This parameter actually defines the speed of instruction rotations. The recommended value is above 20ms. Generally, you do not need to change the value of Maximum Wait time 3 seconds.

When the user uses ZLVircom to select the conversion protocol as "after Modbus TCP to RTU", ZLVricom will automatically check the above two enable boxes (unless the user manually enters the advanced option to remove), and the above two times will be automatically configured according to the baud rate. However, if the Modus command is long or the protocol is converted to None, you need to manually set the two parameters.

The following describes the recommended values for setting the above parameters:

1. Figure 38 shows the RS485 bus collision prevention time. Generally, you can set it to twice the value of Packet Interval in the lower right corner of the parameter configuration page, but the value cannot be less than 20.
2. Figure 37 shows the "RS485 command response timeout time", which is generally

---

determined by the length of the command to and from the reply. If the send command is N bytes and the reply is M bytes, the recommended value is "packet interval" x (N+M+5) +100.

#### 7.6. Modbus under Multi-destination IP

As shown in Figure 36, if the serial port device (RTU device) acts as the primary station and the network port device (Modbus TCP device) acts as the secondary station, there are multiple network port secondary devices at the same time. In this case, you can use the serial port server as a client to connect to multiple network ports. For details, see 5.2.2 Connecting a Client to Multiple Servers.

In this case, the following functions need to be implemented: When the serial port RTU sends commands to multiple network port devices, the network port device identifies whether to send commands to itself through the Slave ID field, and only the network port device corresponding to the Slave ID responds. After the network port response is sent to the serial port server, it is converted into an RTU command and sent to the RTU device through the serial port.

At this time, it should be noted that the two check marks "RS485 bus collision prevention time" as shown in Figure 38 and "RS485 command response timeout time" as shown in Figure 37 need to be removed. Otherwise, the preceding forwarding function cannot be implemented.

Another application method is: Although the serial port server is connected to multiple network port devices as a Client, the RTU device is not the master station, but the network port device sends first, and the RTU device replies (as the slave station). In this case, the two checkboxes of RS485 bus Conflict Prevention time and RS485 command response timeout time need to be selected, so that multiple hosts can access an RTU device at the same time.

#### 7.7. Configurable Modbus gateway

For configurable Modbus gateway ZLMB, please refer to "Four Types of Modbus Gateway" [http://www.zlmcu.com/document/Modbus\\_Gateway.html](http://www.zlmcu.com/document/Modbus_Gateway.html).

---

## 8. Registration package and heartbeat package

Registration packets and heartbeat packets are a feature suitable for communication between devices and cloud software.

### 8.1. Registration Package

The definition of the registration package is that when the computer software and the serial port server module (hereinafter referred to as the module) establish a TCP connection, the module will first send a string of codes to the software, so that the software can know which module is communicating with itself. This string of codes is the registration package.

The registration package is very suitable for the monitoring of the Internet of things, because the cloud software generally runs on the public network server on the Internet, and the modules are scattered in various collection and monitoring points. How to make the cloud software identify the module is very important, and it is necessary to achieve Internet of Things communication.

Shanghai Zlan serial server provides the following registration methods.

#### 8.1.1. Send the MAC address when connected

Send MAC address on connection: When the module is connected to the cloud, it sends its mac address to the cloud. Since the MAC address is unique, the device can be uniquely identified. This method is simple and effective because it does not require registration package writing for each device. How to use: click "More Advanced Options" in the device Settings dialog box, find "Send MAC address when TCP is established" in the upper middle, tick in the front, and then return to the Settings interface, click "Modify Settings".




Figure 39 Send MAC address via connection

### 8.1.2. Realcom Agreement

Realcom protocol is a mature protocol containing registration packets and heartbeat packets. Users can use this protocol to realize registration packets and heartbeat packets. To enable the Realcom protocol, perform the following operations: In the Device Settings dialog box, set Conversion Protocol to REAL\_COM protocol. Note that the part of enabling the registration package must be left blank.




Figure 40 Enable realcom protocol

After a TCP connection is established between the device and the cloud, the

---

device automatically sends a hexadecimal registration packet FA 07 13 02 FA 02 MAC[5] MAC[4] MAC[3] MAC[2] MAC[1] MAC[0] FA FF. MAC[5] to MAC[0] indicates the MAC address of the device.


1. When the device sends data to the network, it automatically adds the three-byte prefix FA 01 01.

2. At a keepalive interval, the device sends a 1-byte heartbeat packet of 00 to the software.

The REAL\_COM protocol can be used as the registration package of the device because the registration package contains the MAC address. However, due to its fixed format, only cloud software can design the REALCOM protocol to be compatible with this approach.

### 8.1.3. Custom Registration Package

The custom registration package mode allows the user to fill in any registration package format. The method is as follows: On the device Settings screen, configure as follows:



The screenshot shows a settings interface with a light blue background. It contains several configuration fields: 'Transfer Protocol' is a dropdown menu set to 'REAL\_COM Protocol'; 'Keep Alive Time' is a text box with '60' and '(s)' next to it; 'Reconnet Time' is a text box with '12' and '(s)' next to it; 'Http Port' is a text box with '80'; 'UDP Group IP' is a text box with '230 . 90 . 76 . 1'; and 'Register Pkt:' is a checked checkbox followed by a text box containing '31323334' and an unchecked checkbox labeled 'ASCII'.

Figure 41 Set up register packet

The difference with the REAL\_COM protocol is that the registration package is enabled and the registration package information such as 31, 32, 33, 34 is filled in. Note that this is in hexadecimal, which means that the actual data sent is the string 1234. If you want a string display, click the "ASCII" option next to it.

When the device is connected to the cloud software, it can automatically send the hexadecimal registration package of 31, 32, 33, and 34. This registration package method is more flexible, allowing the device to adapt to the existing cloud registration

---

package format; However, there is no wildcard such as MAC in the registration package, so you need to configure a different registration package for each device, which is complicated. The above two methods of sending MAC addresses and REALCOM are the same for each device, but the registration package is naturally different due to different MACs.

The maximum registered package length is 33 bytes. This mode supports registered packets and heartbeat packets in UDP mode.

#### 8.1.4. Configuration file


The 5143K series supports the serial port server to write a configuration file, so that users can fully customize the registration package, and can use MAC address wildcards, which can solve the problem of writing a custom registration package for each device, and there is no limit on the length of the registration package.

#### 8.2. Heartbeat Packet

The heartbeat packet is used to detect whether the communication link is down. The method of implementation is that every once in a while the device sends a heartbeat packet data to the server software, and the data will be discarded after the server receives it, and will not be regarded as valid communication data.

The heartbeat packet has two main functions: first, it can let the upper computer software know that the device is in the active state; Secondly, if the device fails to send the heartbeat, the device on the TCP client will automatically re-establish the TCP connection, so it is a means to restore network communication.

---



Advanced Settings	
DNS Server IP	8 . 8 . 4 . 4
Dest. Mode	Dynamic
Transfer Protocol	REAL_COM Protocol
Keep Alive Time	60 (s)
Reconnect Time	12 (s)
Http Port	80

Figure 42 Keepalive timing time

As shown in Figure 42, the sending time of the heartbeat packet is set by the Keepalive Timing time.

### 8.2.1. Implied Heartbeat

Even if no heartbeat packets are set, the implicit heartbeat function is enabled on the Zlan device when the TCP client is deployed. Therefore, the implied heartbeat function means that the device sends data but the server does not receive the heartbeat data. Therefore, it can not play the first function of the heartbeat packet, that is, the function of the server to detect the activity of the device; However, because the device actually sends data, it can play the second function of the heartbeat packet, that is, the function of the device to detect whether the TCP connection is normal. Once the connection is detected, the TCP connection can be automatically re-established.

### 8.2.2. REALCOM Protocol


As described in 8.1.2Realcom protocol, the REALCOM protocol can send a 1-byte data of 00 at every keepalive interval. This data is the heartbeat packet of the realcom protocol.

### 8.2.3. Custom Heartbeat packs

Fill in the registration package by following instructions in 8.1.3 Customizing the Registration Package. Then add heartbeat packets as follows: Click the "More Advanced Options" button in the device Settings, write the hexadecimal heartbeat packet in the second line of the multi-destination IP and port, and change the option

---

on the right to "Parameter packet Destination".



IP Address or DNS name	Port	Type
313233	0	Param. Dest.
616263	0	Param. Dest.

Figure 43 Customize the registration package

The sum of the registered packet and heartbeat packet must be less than 33 bytes. The first line is actually the registration package.

## 9. Httpd Client communication function

This feature is suitable for users who need to integrate device management functions into their own software.

The "UDP Management Port Protocol" has been integrated into the device management function library ZLDevManage. This is a DLL development library for the Windows platform, which can be called by various development tools such as VC, VB, Delphi, etc.

Detailed API interface documentation and VC calling Demo cases are provided. It can achieve device search, parameter modification, P2P function calls, etc.

The development library can be obtained from the ZLan official website: find "Device Management Function Library" on the <http://zlmcu.com/download.htm> page. For details, please refer to "ZLan WinP2p and Device Management Development Library".

## 10. MQTT Gateway

Please refer to the use of MQTT gateway function

《 How to use MQTT gateway 》  
[http://www.zlmcu.com/document/Usage\\_of\\_MQTT\\_Gateway.html](http://www.zlmcu.com/document/Usage_of_MQTT_Gateway.html).《Zlan MQTT and JSON to Modbus Gateway Usage 》  
[http://www.zlmcu.com/document/MQTT&JSON\\_to\\_Modbus.html](http://www.zlmcu.com/document/MQTT&JSON_to_Modbus.html);



---

## 11. JSON TO Modbus RTU

For Modbus RTU to JSON and related JSON usage, see

JSON Data Acquisition Gateway

<http://www.zlmcu.com/document/jsondata.html>;

ZLan Server and the Use of Collection Equipment

<http://www.zlmcu.com/document/zlancloud.html>;

645 instrument in JSON format on the method

[http://www.zlmcu.com/document/645\\_Instrument\\_JSON.html](http://www.zlmcu.com/document/645_Instrument_JSON.html);

Zlan MQTT and JSON to Modbus Gateway

[http://www.zlmcu.com/document/MQTT&JSON\\_to\\_Modbus.html](http://www.zlmcu.com/document/MQTT&JSON_to_Modbus.html);

## 12. NTP time function

For details about how to obtain and use NTP time, please refer to "Zlan NTP Time Module Usage"[http://www.zlmcu.com/document/zlan\\_NTP.html](http://www.zlmcu.com/document/zlan_NTP.html)。

## 13. Modify the parameters of the network port

Network port parameter modification is to realize the function of searching equipment and modifying equipment parameters like zlvircom software, that is, to manage equipment and modify parameters through the network port of serial server. Suitable for users who integrate search and configuration capabilities into their software.

Network port modification parameters are implemented through the UDP Management Port Protocol, for example:

1. The computer software sends UDP broadcast packets whose destination port is 1092 on the network. When the device receives the packet, it will return its information to the computer software to search for the device.
2. The computer software sends the UDP parameter modification command to port 1092 of the device to modify the device parameters.

For details about network port modification parameters, see the ZLAN Network Products UDP Management Port Protocol. It can also be done directly using the

---

device management library of the 14 Device management library.

## **14. Device Management Function Library**

This feature is intended for users who need to integrate device management functions into their own software.

The "UDP management port protocol" has been integrated in the device management function library ZLDevManage. This is a DLL windows platform development library, can be called by VC, VB, Delphi and other development tools.

Provide detailed API interface documentation and VC call Demo cases. It can realize device search, parameter modification, P2P function call and so on.

Development libraries can be obtained from the ZLan's official website: <http://zlmcu.com/download.htm> looking for "equipment management function library" page. For details, please refer to "Zlan WinP2p and Device Management Development Library"

## **15. Serial port modification parameters**

Users can read and set parameters by sending commands to the serial port server's serial port. This is suitable for users who need to control and configure products at the chip or module level through serial port. The parameters that can be set include: IP address, baud rate, device name, working mode, etc. After the new parameters are set, the serial port server can be restarted through serial port commands.

The serial commands of Zlan have the following features:

1. Serial port commands use a 10-byte data preamble, so there is no need to distinguish between communication data and commands by pulling down or pulling up additional configuration pins, nor is there a need to switch between command mode and communication mode, making usage more flexible and convenient.
2. The command set includes various command formats such as saving parameters, not saving parameters, and restarting the device.

- 
3. It can implement a variety of applications, such as reading the MAC address of the serial port server, or modifying the operating mode of the serial port server. For example, when switching from TCP server to TCP client mode, it can actively connect to the server; when switching from TCP client to TCP server mode, it can disconnect from the server connection.

Please refer to "Serial Port Parameter Modification and Hardware TCP/IP Stack Protocol" for detailed operation methods on modifying serial port parameters.

## 16. Remote device management

Remote device management refers to the ability to maintain and manage devices through ZLVircom software, including restarting devices, modifying parameters, and updating firmware. This feature is suitable for users who manage devices through ZLVircom.

For ZLVircom software, as long as the device can be found in the device list, remote management can be performed. Remote management of devices can be divided into the following situations:

1. Automatic search: Under the same switch, regardless of whether they are on the same network segment, the way ZLVircom searches for devices on a computer is: ZLVircom sends a broadcast query (all devices receive the query and reply with their parameters to the ZLVircom tool. This method searches for all devices at once.)




Figure 44 automatic search

2. Manually add: There are two situations:





Figure 45 manually added

- a) Large routers divide the network: In some large networks, broadcast packets are divided by routers, so broadcast packets cannot reach the device end, but pinging the device IP is always through. At this point, manual addition is

---

generally needed to solve the problem. The method of manual addition is to click "Manual Addition" in the "Device Management" dialog box to add the first and last IP for individual queries of the device.

- b) Public network server queries internal network devices: Serial servers are in the internal network and operate in TCP server mode, while zlvircom is on a server with a public IP. At this point, a UDP port mapping of 1092 needs to be set up on the router of the network where the device is located, mapping to the IP of the device, and then zlvircom manually adds this device, with the IP being the public IP of the device end.
3. TCP Client: When the device acts as a TCP client, it will initiate a TCP connection to the destination IP (116.15.2.3) on port 4196. Once the connection is established, it will automatically send its parameter system to the destination's UDP port (not the TCP port) every keep-alive time interval, allowing zlvircom to detect the device on this computer (116.15.2.3). If the destination port is not 4196, you will need to modify zlvircom's default parameter receiving port by changing the menu/config/software configuration/default listening port. After starting zlvircom, if a TCP port conflict message appears, ignore it and continue with the execution.



The screenshot shows a configuration window for zlvircom. The 'Work Mode' is set to 'TCP Client'. The 'Net Mask' is '255 . 255 . 255 . 0'. The 'Gateway' is '192 . 168 . 1 . 1'. The 'Dest. IP/Domain' is '116.15.2.3' with a 'Local IP' button next to it. The 'Dest. Port' is '4196' with a checkbox for 'UDP Dynamic' which is currently unchecked. A red rectangle highlights the 'Dest. IP/Domain' and 'Dest. Port' fields.

Work Mode	TCP Client
Net Mask	255 . 255 . 255 . 0
Gateway	192 . 168 . 1 . 1
Dest. IP/Domain	116.15.2.3 Local IP
Dest. Port	4196 <input type="checkbox"/> UDP Dynamic

Figure 46 Client

4. Scheduled transmission parameters: Even when in TCP server mode, the serial server can select the "Scheduled Transmission Parameters" feature to send parameters every 5 minutes to the destination IP (here, 116.15.2.3) on the destination port. The zlvircom on this server's port can receive parameters and manage these devices.

Work Mode	TCP Server	Keep Alive Time	60 (s)
Net Mask	255 . 255 . 255 . 0	Reconnet Time	12 (s)
Gateway	192 . 168 . 1 . 1	Http Port	80
Dest. IP/Domain	116.15.2.3 Local IP	UDP Group IP	230 . 90 . 76 . 1
Dest. Port	1024 <input type="checkbox"/> UDP Dynamic	<input type="checkbox"/> Register Pkt:	<input type="checkbox"/> ASCII
Serial		<input type="checkbox"/> Restart If No Data	every 300 Sec.
Baud Rate	115200	<input checked="" type="checkbox"/> Enable Parameter Send	every 5 Min.

Figure 47 Timing transmission parameters

To facilitate the identification of devices, if remote management is required, please name the device something easy to remember.

## 17. Firmware upgrade method

ZLAN5143K can upgrade individual programs, but not each other. You can use this method to upgrade the firmware of devices found in the device list by automatic search, manual add, or P2P search.

- 1 Get ZLSN2007 firmware files from ZLAN, such as 1.452(2007).bin.
- 2 In the ZLVircom tool, first search the device that needs to be upgraded, and then enter the device parameter editing dialog box. First click "Restart Device" once.



Figure 49 Upgrade button

After the device restarts, use the same method to search for the device and enter the dialog box again. Click the "Firmware and Configuration" button in the lower right corner of the dialog box.



Figure 50 Upgrade button

- 3 Select the "Program File Download" option, as shown in Figure 50. In the

program file, select the firmware file. The IP address of the serial port server is automatically filled in, and the module type/model is automatically selected. Then click Download.




Figure 50 ZLSN2007 firmware upgrade method

- 4 At this time, the download progress bar starts to move, and the download time is about 30 seconds. During the download process, you will see the ACT light of the device blink, and at the end of the download, you will see the LINK light blink several times. Then the program pops up "transmission completed LINK light flashing device do not power off" prompt box. Note: This is only the completion of transmission, write to the flash process takes about 3 seconds, at this time the LINK light will blink, during this period please do not power off.
- 5 After downloading the general program will automatically restart, generally do not need to power off. If the running indicator is blinking, stop the LINK indicator blinking for more than 30 seconds and power it on again.
- 6 Web Configuration interface update: After the firmware upgrade, the configuration page inside the module also needs to be updated. Otherwise, the configuration cannot be configured through the Web, but the communication will

not be affected. It is also possible not to download web pages without web configuration. The method of downloading Web is: as shown in Figure 51, change the download mode of "program file" to "Web directory download". In addition, select the root directory of the local web page as the directory of the web file to be downloaded (this directory can be obtained from ZLAN), and click Download to download all files in the local web page directory to the internal file system of the device.




Figure 51 web upgrade method

## 7 Look out:

- 7.1 If the message "Download failure" is displayed, the device will not be damaged. You can download the device again. In addition, when the LINK light blinks at the end of the download, do not power off, otherwise the device will be damaged.
- 7.2 Check the firmware version through ZLVircom to know whether the new firmware has been downloaded successfully.

---

## 18. Ordering Information

Table 8 Ordering information

Model number	Instructions
ZLAN5143K	Ordinary model
ZLAN5143KN	With P2P function

## 19. After-sales service and technical support

Shanghai Zlan Information Technology Co., Ltd.

Address: Room 2001, No. 28 Yuanwen Road, Minhang District, Shanghai

Phone: 021-64165189

Fax: 021-64165200

URL: <http://www.zlmcu.com>

Email: [support@zlmcu.com](mailto:support@zlmcu.com)